

7929 Lincoln Ave. Riverside, CA 92504
 Phone: 951.689.ICON Fax: 951.689.1016

PART #	DESCRIPTION
214207	14-UP RAM 2500 REAR SWAY BAR LINK KIT

COMPONENTS INCLUDED	
(2) 214112 14+ RAM HD REAR SWAYBAR LINK	(1) 214207H HARDWARE KIT
HARDWARE INCLUDED	
214207H HARDWARE KIT	
(4) 139001 SLEEVE .625 X .508 X 1.625 (8) 297024 SWAY BAR URETHANE BUSHING	(4) 605835 M12-1.75 X 70MM BUTTON HEAD BOLT (4) 605838 M12-1.75 X FLANGED LOCK NUT
TOOLS REQUIRED	
TORQUE WRENCH 8MM ALLEN WRENCH	8MM SOCKET / WRENCH 18MM SOCKET / WRENCH
TECH NOTES	
<p>1. THESE SWAY BAR LINKS WILL ALLOW A SHOCK IN THE STOCK LOCATION TO BE UP TO 27.5" LONG.</p>	



WARNING!

**** READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION! IF THESE INSTRUCTIONS ARE NOT PROPERLY FOLLOWED SEVERE FRAME, SUSPENSION AND TIRE DAMAGE MAY RESULT TO THE VEHICLE!**

**** ICON VEHICLE DYNAMICS RECOMMENDS THAT YOU EXERCISE EXTREME CAUTION WHEN WORKING UNDER A VEHICLE THAT IS SUPPORTED WITH JACK STANDS.**

**** ICON VEHICLE DYNAMICS RECOMMENDS ALL INSTALLTION TO BE PERFORMED BY A PROFESSIONAL SHOP/SERVICE TECHNICIAN. PRODUCT FAILURE CAUSED BY IMPROPER INSTALLATION WILL NOT BE COVERED UNDER ICON'S WARRANTY POLICY.**

INSTALLATION

1. Disconnect the rear sway bar links from the sway bar and the frame using an 8mm and 18mm socket/wrench and remove.
2. Grease the hat bushings for the sway bar links and slide them in. Slide the bushing sleeve through the bushings.
3. Install the sway bar links using the supplied 12mm hardware. Tighten using an 8mm and 18mm socket/wrench. [Torque to 65 ft-lbs] [FIGURE 1]

FIG.1



4. Check the torque on all hardware. Drive the truck 1-2 miles and re-torque all nuts and bolts.

VERIFY ALL FASTENERS ARE PROPERLY TORQUED BEFORE DRIVING VEHICLE.

RETORQUE ALL NUTS, BOLTS AND LUGS AFTER 100 MILES AND PERIODICALLY THEREAFTER.

ICON VEHICLE DYNAMICS LIMITED LIFETIME WARRANTY

ICON Vehicle Dynamics warrants to the original retail purchaser who owns the vehicle on which the product was originally installed. ICON Vehicle Dynamics does not warrant the product for finish, alterations, modifications and/or installation contrary to ICON Vehicle Dynamics instructions. ICON Vehicle Dynamics products are not designed, nor are they intended to be installed on vehicles used in race applications, for racing purposes or for similar activities. (A "race" is defined as any contest between two or more vehicles, or a contest of one or more vehicles against the clock, whether or not such contest is for a prize). This warranty does not include coverage for police or taxi vehicles, race vehicles, or vehicles used for government or commercial purposes. Also excluded from this warranty are sales outside of the United States of America and Canada.

ICON Vehicle Dynamics' obligation under this warranty is limited to the repair or replacement, at ICON Vehicle Dynamics' discretion, of the defective product. Any and all costs of removal, installation or re-installation, freight charges and incidental or consequential damages are expressly excluded from this warranty. Items that are subject to wear are not considered defective when worn and are not covered.

ICON Vehicle Dynamics components must be installed as a complete kit as shown in our current application guide. Any substitutions or exemptions of required components will immediately void the warranty. Some finish damage may happen to parts during shipping and is not covered under warranty.

This warranty is expressly in lieu of all other warranties expressed or implied. This warranty shall not apply to any product that has been improperly installed, modified or customized subject to accident, negligence, abuse or misuse.

ICON VEHICLE DYNAMICS

PERFORMANCE SUSPENSION SYSTEMS AND SHOCK ABSORBERS

7929 Lincoln Ave. Riverside, CA 92504 Phone: 951.689.ICON Fax: 951.689.1016
www.iconvehicledynamics.com



FOLLOW US ON FACEBOOK!

