

### Parts List

- |   |                           |
|---|---------------------------|
| 1 | Fairlead bracket, 15600FB |
|---|---------------------------|

### Level of Difficulty

Easy



Scan for helpful install tips

### Installation Instructions

- Position the 15600FB fairlead adapter over the holes on your ARIES modular front bumper.
- Loosely assemble a compatible roller fairlead to the front mounting holes in the adapter as shown. The bottom mounting locations are recommended for most bottom wound winches.  
  
Use the mounting hardware supplied by the roller fairlead manufacturer with the bolts heads installed from the winch side of the adapter.

- With the fairlead loosely installed, place a compatible winch on top and align the mounting holes with the bracket and bumper below it.  
  
Use the winch manufacturers mounting hardware and installation instructions to attached the winch to the center bumper section.

- With the winch in position, torque all hardware to the manufacturers recommended torque.
- Thread the winch cable through the opening in the roller fairlead and attached the tow hook.
- Congratulations on the installation of your brand new ARIES winch plate.

### Notes and Maintenance

Before you begin installation, read all instructions thoroughly.

Never exceed the vehicle, winch or fairlead brackets rated capacities.

Refer to the winch and fairlead manufacturers operating instructions and warnings before using the installed product.

Improper use or installation may result in failure.

### Product Image



Figure 1

