



®

# INSTALLATION INSTRUCTIONS

## Tube Kit 37171 for Jeep Wrangler TJ

Must be used with Winch Mount 37170  
and standard front bumper only.

