



## INSTALLATION INSTRUCTIONS

**Tube Kit 61858 for  
Jeep Wrangler YJ**

**MAY ONLY FIT WITH  
WARN front bumper**

1. If the vehicle is equipped with a winch plate, remove any spacers that may be between the winch plate brackets and the top of the bumper. Remove the four top bumper bolts.
2. If the vehicle has a winch, lift the winch and plate up and slip the grill guard between the top of bumper and winch plate. If the vehicle has no winch, place the grill guard on top of the bumper.
3. Install the four top bumper bolts that were removed. Torque the ½" bolts to 50-55 ft/lbs.

