



INSTALLATION INSTRUCTIONS

**DIFFERENTIAL SKID PLATES:
DANA 30, DANA 30HP, DANA 35, DANA 44,
DANA 44HP, DANA 60, DANA 60HP,
FORD 8.8, AND AMC 20**

INSTALLATION TO VEHICLE:

1. Remove bottom five bolts from differential cover.
2. Place skid plate to differential and align mounting holes.
3. Install differential skid plate using the button head capscrews provided in the kit.
4. Torque capscrews to 17-19 ft. lbs.. **(Except Dana 60 and Dana 60hp torque to 30-35 ft. lbs.)**

NOTE: It may be necessary to remove the OE differential cover and reseal it to the axle housing when installing the differential skid plate. Removing the bottom bolts to install the differential skid plate may cause a leak in the seal. Please check with the car dealership where your vehicle was purchased. In some cases it may be necessary to have an OE Service Center reseal it to maintain the vehicle warranty.