



Installation Instructions KC 7307 Light Bracket for 1½, 1¾ or 2 inch Tubular Bar

Thanks for choosing a KC HiLITES product. We take pride in building the highest quality, best engineered systems possible. Your satisfaction with our product is important, so if you have any questions, please call our customer service line at 800-528-0950.

Parts Included:

- | | |
|---|--|
| 1 - Light bracket (2 pieces) | 4 - Allen (3/16" head) bolts ¼"-20 x 1½" |
| 4 - Square nuts ¼"-20 | 4 - Washers ¼" |
| 4 - Rubber spacers 2 ¾"x 2 5/16" x 1/8" | 1 - Instructions |

Installation

For 1½" Bar - You must use all four spacers. Cut ¼" off of the longer length on two of the spacers. Set these aside. Remove the paper backing on the two uncut spacers. Push one into each of the two halves of the bracket so they do not overhang any of the edges. Now remove the paper from the two cut spacers and put one in each of the two halves also allowing no overhang.

For 1¾" Bar - You will only use two of the spacers. Remove paper and align one in each half of the bracket as described above.

For 2" Bar - No spacers needed

Continue Installation

1. Fit both halves around the bar.
2. Slide a lock washer onto one of the bolts and insert it through one of the bottom holes. Add a nut and tighten bolt only enough to hold nut in place.
3. Loosely add the other three bolts with washers and nuts.
4. Position and level the bracket to fit your needs. Tighten all bolts evenly by

