



Installation Instructions KC 7309 Light Bracket for 2 $\frac{3}{4}$ and 3 inch Tubular Bar

Thanks for choosing a KC HiLiTES product. We take pride in building the highest quality, best engineered systems possible. Your satisfaction with our product is important, so if you have any questions, please call our customer service line at 800-528-0950.

Parts Included:

- | | |
|--|---|
| 1 - Light bracket (2 pieces) | 4 - Allen (3/16" head) bolts 1/4"-20 x 1 3/4" |
| 4 - Square nuts 1/4"-20 | 1 - Instructions |
| 2 - Rubber spacers 2 5/16" x 4 3/8" x 1/8" | |

Installation

For 2 $\frac{3}{4}$ " Bar - You will need to use the two spacers supplied.
Align one in each half of the bracket so they do not overhang any of the edges.

For 3" Bar - No spacers needed

Continue Installation

1. Fit both halves around the bar.
2. Insert one of the bolts through one of the bottom holes. Add a nut and tighten bolt only enough to hold nut in place.
3. Loosely add the other three bolts and nuts.
4. Position and level the bracket to fit your needs. Tighten all bolts evenly by alternating diagonally one turn per bolt each time until secure.

