



Thank you for choosing Rough Country for all your suspension needs.

**NOTICE**

Please read instructions before beginning installation. Check the kit hardware against the kit contents below. Be sure you have all needed parts and know where they go.

**KIT CONTENTS**

RC Tailgate Vent  
(2) 1/2" Grommets  
(1) 25mm Grommet

**TOOLS NEEDED**

13mm Socket/Wrench  
Flat Blade Screwdriver

**INSTALLATION INSTRUCTIONS**

1. Open tailgate, remove vent. **See Photo 1.**
2. Carefully unplug the 3rd brake light wiring harness and reinstall the vent. **See Photo 2.**

**PHOTO 1**



**PHOTO 2**



3. Close tailgate, remove rubber grommet holding the 3rd brake light wires. **See Photo 3**
4. Using a 13mm socket, remove the spare tire mount from the tailgate. **See Photo 4.**

**PHOTO 3**



**PHOTO 4**



5. Remove the factory vent by gently pulling it out of the tailgate.
6. Carefully pull to remove the tire bump stops from the tailgate.

**▲ NOTICE** If using a bumper/ tire carrier combo, DO NOT REMOVE the tire bump stops!

7. Install the RC tailgate vent using the factory hardware. Tighten using a 13mm wrench or socket. **See Photo 5.**
8. Install the supplied grommets into the holes on the tailgate. The 2 smaller grommets will be in place of the tire bumpers and the larger will be in place of the 3rd brake light wiring grommet. **See Photo 6.**



By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable , State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

