

INSTALLATION INSTRUCTIONS Rear Wheel Well Inner Liner **CHEVY 2014+**





INSTALLATION INSTRUCTIONS Rear Wheel Well Inner Liner CHEVY 2014+

7. Locate the pre-drilled hole located below the frame edge. Install one SMALL push pin provided.



For trucks WITH factory Mod Flaps

8. b) Re-install the Mod Flap using the 2 screws saved in step 3.



10. Re- Install the tire



Care and Maintenance Recommendations To protect the appearance of this product, wash with soap and water

For trucks WHITOUT factory Mud Flaps

8. a) Locate the pre-drilled hole at the bottom front inner corner of the WW Inner Liner and install one BIG push pin provided



9. Locate 5 pre-drilled holes on the body of the Inner Wheel Well Liner, and install one of the BIG push pins in each hole



Repeat steps 2 - 10 on driver's side