

2007-2014 Jeep Wrangler JK 2 Door

RCJ0746, RCJ1246

Bolt Kit (Included in step box)

- (12) 5/16" threaded clips
- (12) 5/16" bolts
- (12) 5/16" washers

Tools Needed:

- Ratchet
- 3/8" socket
- 1/2" socket
- 9/16" socket
- 10mm socket
- Drill and 3/8" drill bit
- Marker



Step 1. Find both the driver and passenger side steps.

Note: The hoop step is nearest to the rear of the main tube.

Step 2. Line up the passenger side step brackets with existing holes in the pinch weld. Mark, and drill holes with a 3/8" drill bit. Even existing holes must be drilled out to accommodate the supplied bolts.

Step 3. Place threaded clips in each mounting location on the vehicle.

Step 4. Loosely install the supplied bolts in each mounting location. After all bolts have been engaged, tighten beginning with the bolts on the pinch weld.

Step 5. Repeat this process for the driver side of the vehicle.

Products licensed to Rough Country by Fichter Designs are protected by US patent law and International Copy Right law. US Patent # 6855783, # 6874801, # 7416202 apply. Other patents and continuances pending. Products configuration also protected by International Trade Dress Law. All Design and Patent infringements will be prosecuted to the full extent of the law.

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable Federal, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items