

JEEP WRANGLER TJ REAR PANHARD ROD

EXTENSION MOUNTING BRACKET

Part Number FKWTJ02 - Left Hand Drive Models Only

CONTENTS:

Quantity	Description
1	Panhard Rod Extension Bracket
1	Panhard Rod Spacer
1	Bolt M12 x 1.25 x 25mm
1	Bolt M12 x 1.25 x 65mm
1	Bolt M10 x 1.25 x 25mm
4	Washer Flat 12mm
2	Nut M12 x 1.25ZP
1	Nut M10 x 1.25ZP
2	Washer Spring 12mm
1	Washer Spring 10mm
2	Washer Flat 10mm

FITTING INSTRUCTIONS:

1. Disconnect the rear sway bar at the bottom end of the linkage.
2. Disconnect the rear driver's side shock absorber.
3. Disconnect the rear panhard rod at the axle end and save the hardware.
4. Jack up the rear of the vehicle from the bumper or the frame to allow the rear driver's side coil to relax. Make sure the vehicle is secured with jack stands.
5. Remove the rear driver's side wheel and coil spring.
6. Remove the plastic shroud from the top of the panhard rod mounting fixture. This fixture is welded to the axle tube on the driver's side.
7. Fit OME extension bracket to the top of the mounting fixture using OME panhard rod spacer in original mounting hole. Secure with 65mm x 12mm bolt through hole "B" at the rear.
8. Using the extension bracket as a template, drill through the fixture at holes "A" and "C". Hole "A" should be drilled to 1/2 inch and hole "C" should be drilled to 7/16 inch.
9. Permanently secure the extension bracket to the fixture using provided hardware.
10. Reinstall the coil spring and shock absorber.
11. Reinstall the wheel.
12. Remove the jack stands and lower the vehicle to the ground.
13. Reinstall the panhard rod to the extension bracket using the original bolt.
14. Reconnect the sway bar linkage.

(Refer overleaf for diagram)

