



491 W. Garfield Ave., Coldwater, MI 49036

Phone: 517-279-2135

Web/live chat: www.bds-suspension.com

E-mail: tech-bds@ridefox.com

Part#: 101001, 104002, 104006

Extended Brake Lines

2007-2012 Jeep Wrangler JK, 1988-1998 Chevy Truck

READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.

PARTS LIST

101001 Chevy Front Brake Lines

Part #	Qty	Description
22510	2	Front Brake Line
5188	2	Snap In Brake Line Clip
CCW-03-050	4	3/8 Brake Line Crush Washer
099000	2	11.5in Nylon Cable Tie - Black

104002 Jeep JK Front Brake Lines

Part #	Qty	Description
B06103C	2	Brake Line L-Bracket
5188	2	Snap In Brake Line Clip
CCW-03-050	4	3/8 Brake Line Crush Washer
22542	1	Jeep JK Front Brake Line - DS
22543	1	Jeep JK Front Brake Line - PS

104006 Jeep JK Rear Brake Lines

Part #	Qty	Description
B06103C	2	Brake Line L-Bracket
5188	2	Snap In Brake Line Clip
CCW-03-050	4	3/8 Brake Line Crush Washer
22540	1	Jeep JK Rear Brake Line - DS
22541	1	Jeep JK Rear Brake Line - PS

INSTALLATION INSTRUCTIONS

1. Park the vehicle on a clean, flat surface and block the wheels for safety.

 Note: This installation can be done with or without the wheels installed. Access to the brake lines is better with the wheel removed but it is not necessary.

Perform this installation on one side of the vehicle at a time.

2. Disconnect the rubber brake line from the hard line at the frame. On Chevy models disconnect the rubber line from the frame mount. On newer Jeep JK's, there is an additional bracket at the coil bucket that will need to be removed.
3. Disconnect the rubber brake line from the caliper by removing the banjo bolt. Retain bolt and discard original crush washers and brake line.
4. Install a new crush washer on the OE banjo bolt and install the bolt in the end of the new stainless steel brake line followed by a second crush washer. Attach the entire assembly to the caliper and torque the bolt to 20 ft-lbs.
5. Chevy Models: Route the new line up to the frame so that it will not rub against any heated or rotating objects. Run the fitting of the brake line in the factory frame bracket and attach to the hard line. Tighten securely.
6. Jeep JK models: A new frame bracket is provided. Secure bracket to the frame with the factory bolt. Route the new line up to the frame so that it will not rub against any heated or rotating objects. Run the fitting of the brake line in the new frame bracket and attach to the hard line. Tighten securely.
7. Retain the new line to the frame bracket with the provided retaining clip.
8. Repeat on other side of the vehicle.
9. Completely bleed the brake system starting with the brake furthest away from the master cylinder. Check the brake fluid level. Inspect for leaks.