Head Office: ARB Corporation Ltd Postal Address: PO Box 105, Kilsyth 3137 Australia Street Address: 42 - 44 Garden Street Kilsyth, Victoria 3137 Australia

Tel: +61 3 9761 6622 • Fax: +61 3 9761 6807


www.arb.com.au ABN 31 006 708 756

## **OMEGS19 GREASABLE SHACKLE KIT**

## **CONTENTS**

Part Number	Qty	Description
3199936	2	Side Plate
3199962L	1	Side Plate anti inversion
3199963R	1	Side Plate anti inversion
GSMP14	2	Shackle pin
GSMP15	2	Shackle pin
6151062	8	M14 x 1.5 nut
6151064	8	Spring washers
5728013	4	Grease nipple

## **INSTALLATION PROCEDURE**



RHS SHOWN

- 1. Remove OE shackle plates and pins following manufactures procedures.
- 2. Pre assemble outer side of shackle.
- 3. Lubricate bushes before assembly to assist fitment.
- 4. Fit bushes (supplied separately) to spring eye and vehicle spring hanger.
- 5. Fit shackle assembly with anti inversion point facing toward front of vehicle. (see below)
- 6. Tighten nuts to 81Nm.
- 7. Fit grease nipples and grease assembly using a grease gun.



FRONT OF VEHICLE

ANTI INVERSION POINT TO FACE FORWARD

**RHS SHOWN**