

## HONDA TALON MLC-6 MULTI SWITCH PANEL

**Thank you for choosing Rough Country for all your vehicle needs.**

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.

Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.

Periodically check all hardware for tightness.

### MLC-6 KIT CONTENTS:

Switch Bezel w/6 switches-1  
Relay Pod-1  
Wiring Harness-1

### TOOLS NEEDED:

Phillips Screw Driver  
16mm Wrench or Socket

### HARDWARE INCLUDED:

10mm x 30mm Hex Carriage Head Bolts x2  
10mm Flat Washer x2  
10mm Lock Washer x2  
4-Phillips head Screws




### Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16"	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8"	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16"	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2"	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16"	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8"	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4"	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs




## INSTALLATION INSTRUCTIONS



1. Unlatch the (2) hood latches. Then remove the hood from the UTV. **See Photo 1.**
2. Place the (2) supplied bolts into the upper support to the out side of the slot. **See Photo 2.**




3. Install the MLC-6 onto the bolts. Secure using (2) of the supplied 10mm x 30mm hex head bolts, (2) 10mm washers, (2) 10mm lock washers and (2) 10mm nuts. Tighten using a 16mm wrench. **See Photo 3.**
4. Connect the positive and ground wire to the MLC-6 using a 10mm and 12mm socket. **Torque to 21ft/lbs. Caution! Do not overtighten the power and ground studs.** See Photo 4.



5. Connect the positive and negative light wiring to the MLC-6. **See Photo 5.**
6. Connect the switch bezel harness to the MLC-6. **See Photo 6.**



7. Place the cover onto the MLC-6 and secure using the (2) latches. **See Photo 7.**
8. Route the switch wiring to the center of the dash and connect to the switch pod. **See Photo 8.**



9. Place the switch pod into the void of the dash, use (4) of the supplied Phillip screws to secure the switch pod to the dash. **See Photo 9.**
10. Switch pod shown installed. **See Photo 10.**
11. Connect the MLC-6 power wires to the positive and negative post of the battery.
12. Install the hood.





By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

